




B'SAFE - HELITE

SCHEMATIC MANUAL / NOTICE SCHEMA









Schematische Anleitung / Schematische instructies / Foglio illustrativo
Manual esquemático / Skjematisk manual / Schématický manuál


1.

-  Éléments B'Safe
-  B'Safe Components
-  Die Elemente von B'Safe
-  De elementen van B'Safe
-  Gli elementi del B'Safe
-  Elementos B'Safe
-  B'Safe komponent
-  B'Safe součásti





2.A

-  Associer le capteur selle et la veste.
-  Pair the saddle sensor with the vest
-  Kopplung des Sattel-Sensors mit der Weste
-  Koppel de zadelsensor met het vest
-  Abbinare il sensore della sella con il gilet
-  Aparee o asocie el sensor del sillín con el chaleco
-  Par sete sensoren med vesten
-  Párování sedlového senzoru s vestou



2.B

-  Installer le capteur selle
-  Install the saddle sensor
-  Installation des Sattel-Sensors
-  Installeren van de zadelsensor
-  Installare il sensore sella
-  Instale el sensor del sillín
-  Installer sete sensoren

1.



 Namontujte sedlový senzor

2.B


2. a)




2. b)



3. a)




3. b)




2.C

-  Porter la veste
-  Wear the vest
-  Tragen der Weste
-  Het vest dragen
-  Indossare il gilet
-  Use el chaleco
-  Bruk av vest
-  Noste vestu




5.A.1

-  Allumer / Éteindre B'safe
-  Switch On/Off B'Safe
-  An-und Ausschalten der Weste
-  Het vest Aan / Uitschakelen
-  Accendere / Spegnerne il gilet
-  Encender / apagar el chaleco
-  Slå PÅ/AV B'Safe
-  Zapněte / vypněte B'Safe













5.A.3

-  Recharger la veste
-  Recharging the vest
-  Aufladen der Weste
-  Het vest opladen
-  Ricaricare il gilet
-  Recarga de B'Safe
-  Lading av vest
-  Dobijeni vesty



6.

-  Réutiliser B'Safe après un accident
-  Reuse B'Safe after an inflation
-  Reaktivierung des B'Safe
-  Hergebruik B'Safe na een incident
-  Riutilizzare B'Safe dopo un'inflazione
-  Reutilización de B'Safe después de un inflado
-  Gjenbruk B'Safe etter en utløsning
-  Reaktivace B'Safe po aktivaci



6.

